



Installation Diagram for 1/8" (3mm) Router Bit and Sleeve

The 1/8" (3mm) sleeve is used to hold bits with a 1/8" (3mm) shank in a 1/4" (6mm) collet. See the diagram below illustrating the installation of the router bit and sleeve into a router collet assembly. Make sure the slotted end of the sleeve faces down as shown.

Note: When using a Perske spindle be sure to snap the router collet into the collet nut before inserting the sleeve into the collet.

