

TITLE: **Outputting with OMEGA 3.0**

Category: OMEGA

Gerber FastFact#: 3574

Supplied by: Gerber Service

Last Modified: October 30, 2009

Summary: Unable to output using OMEGA 3.0

ISSUE: Can't output to a Gerber Plotter, Gerber Router, or third party plotter after installing OMEGA 3.0

CAUSE: There are several possible causes.

1. Permissions have not set for the user to output
2. The system is using an OMEGA Layout Station Key rather than an OMEGA CP or CS key.
3. Windows Vista UAC needs to be configured to allow output

SOLUTION:

1. PERMISSIONS: The local user must have privileges to read, write, and modify the following files and folders. *

c:\Queue
c:\Seppath
c:\Windows\gsp.ini
c:\temp or c:\windows\temp
c:\Program Files\ Gerber Scientific Products

*NOTE: It may be necessary for the IT department to log into the PC as an ADMIN in order to set the correct privileges for the user.

2. OMEGA LAYOUT STATION KEY

A system with an OMEGA LAYOUT STATION key can be used to design and save jobs, it cannot be used for output. To output you must have an OMEGA CP, CS, or Plot Station key on the PC.

3. UAC: User Account Control

To configure the UAC: Open Control Panel | User Accounts | Turn UAC on/off or consult your PC Vista documentation for configuring the UAC.