Title: How to Print Quickly on the Gerber Solara ion™ & Gerber CAT | UV™

Product: Gerber Solara ion & Gerber CAT | UV

Document Number: ANote 2010-ion-017

Last Modified: 30 August 2010

Summary: This document provides the quick print checklist from the

Gerber Solara ion & Gerber CAT | UV Owner's Guides.

After you have set up your Gerber Solara ion or Gerber CAT | UV for the first time, use this checklist to help guide you through the steps required to get the machine ready for printing.

Quick-Print Checklist

- 1 Check the lnk Level by pressing the lnk Level button on the control panel. (Replace ink pouches if necessary.)
- 2 Clean the heads. (Repeat every four hours of printing or every two hours of idle time)
- 3 Prep the material. (Normalize and clean for best results)
- **4** Select the material type: Flat or Roll-to-Roll (Single or Continuous)
- **5** Load the material. (Flat or Roll-to-Roll)
- **6** Adjust the UV shield for flat material or adjust the material hold-downs for roll-to-roll material.

Using your selected RIP software

- 7 Open, adjust and arrange your image(s).
- 8 Select appropriate material profile and page size.
- **9** Select the print quality / mode. (ion: 2-pass, 4-pass or 8-pass print mode; CAT | UV: Performance, Production, Quality)
- 10 Send the job to the printer.
- 11 View job information to confirm that the correct material is loaded.
- **12** Press RUN JOB to begin printing your job.
- **13** UV lamps will warm-up. (If lamps are not to proper temperature)
- 14 Job will begin printing.

©2010 Gerber Scientific, Inc. All Right Reserved