

TITLE: Changing the ACPI HAL to STD PC in Win 2000 and Win XP

Gerber FastFact #: 3547

Supplied by: Technical Software Support

Last Modified: August 12, 2002

Summary: This is the procedure to change the ACPI HAL to STD PC in Windows 2000

and Windows XP

---IMPORTANT NOTICE---

This procedure may cause some computers to be inoperable. Do so at your own risk. It is recommended that you first check the manufacturer for the latest bios update.

For Windows 2000.

Right click on my computer, then select the following. Properties, hardware, Device manager, Double click on Computer at the top, Advanced Configuration and power Interface (ACPI), driver, select update driver, next, select display a list of the known drivers for this device, next, show all hardware of this device class, select standard PC, next and finish.

For Windows XP

Click on Start, Control Panel, system, hardware, Device manager, computer, ACPI Uniprocessor PC, driver, update driver, install from a list or specific location (Advanced), next, select Don't search I will choose the driver to install, next, select Standard PC, next and finish.

When you go back into computer under Device manager it should now say STD P.C.